

Navy NP





900**	472**	1
900**	472**	1
520**	470**	1
470**	195**	3 1
1460**	385**	1
374*	414	3
460*	414	1
400*	120	3
400*	120	3
403*	120	3
1490**	444	1
1490**	444	1
460**	444	1
460**	444	1
1512**	444	1
295*	424	1
460*	68	4
374*	68	2
538	470	1
305	470	1
633	234	2 1
1500	384	1
413	395	3
620		1
1700	480/50	2
	900** 520** 470** 1460** 374* 460* 400* 403* 1490** 460** 1512** 295* 460* 374* 538 305 633 1500 413 620	900**472**520**470**470**195**1460**385**374*414460*414400*120400*120403*1201490**4441490**444460*4441512**444295*424460*68374*685384703054706332341500384413395620





PROFIJT























11

PROFIJT



























GB Urgent advice:

If you have bought a high wall cabinet, we ask you to first flatten the furniture at the desired location and then fix it to the wall with the pre-assembled strips. This to prevent possible tilting of the cabinet and preventing anyone to get injured. Plugs and screws for mounting the cabinet to the wall, are not included because the kind of plugs and screws you need is depending on the type of wall. We recommend to buy it from your local hardware store and ask for advice if necessery. After drawing and drilling (whit the right drill), place the plug before screwing the strip. Prevent incorrect assembly or injury of any kind.

