


Montagehandleiding Jumila

	Ax1	Bx2	Cx2	Dx1	Ex8	Fx4	Gx1	Hx12	Ix1
				 M8x20mm	 M6x25mm	 M6x35mm	 M8φx16x1.2	 M6φx16x1.2	 M6

STEP1




STEP2




STEP3




STEP4




STEP5



STEP6



STEP7



STEP8

